

Condensation and Evaporation of Hexane in Nanoporous Alumina Membranes

Hermann Böttcher¹ Victor Doebele² Pierre-Etienne Wolf²
Panayotis Sphatis² Fabien Souris²

¹University of Constance

²Institut Néel, Centre national de la recherche scientifique

02/10/2018

Overview

- 1 Context
- 2 Goals of the internship
- 3 Theoretical background
- 4 Experimental setup
- 5 Conclusions

Context

Grand scheme

- Condensation and evaporation of fluids in confinement

Context

Grand scheme

- Condensation and evaporation of fluids in confinement
- Dependency on
 - pore diameter
 - temperature (relative to the critical temperature)

Context

Grand scheme

- Condensation and evaporation of fluids in confinement
- Dependency on
 - pore diameter
 - temperature (relative to the critical temperature)

Plan

- Anodized alumina membranes (AAM)
- Test setup using Hexane → working at room temperature permits much faster executable experiments
- Transfer to **helium** experiment

Goals

Goals

- Improving and **systemizing** the evaluation of the recorded isotherm data
- Performing isotherm measurements on many membranes for **statistics**

Goals

- Improving and **systemizing** the evaluation of the recorded isotherm data
- Performing isotherm measurements on many membranes for **statistics**
- Comparing the pore diameters extracted from the volumetric measurements those from scanning electron microscopy (SEM) images



Goals

- Improving and **systemizing** the evaluation of the recorded isotherm data
- Performing isotherm measurements on many membranes for **statistics**
- Comparing the pore diameters extracted from the volumetric measurements those from scanning electron microscopy (SEM) images
- Improving the fabrication process to reduce the dispersion



Goals

- Improving and **systemizing** the evaluation of the recorded isotherm data
- Performing isotherm measurements on many membranes for **statistics**
- Comparing the pore diameters extracted from the volumetric measurements those from scanning electron microscopy (SEM) images
- Improving the fabrication process to reduce the dispersion
- Testing the efficiency of the ALD process as a means to reduce the pore diameters


Condensation in a cylindrical open pore



Evaporation in a cylindrical open pore




Condensation and evaporation in a cylindrical open pore




Open cylindrical pore

Condensation at spinodal pressure and evaporation at equilibrium pressure yield a **hysteresis**.




Condensation and evaporation in a cylindrical open pore



Closed cylindrical pore


Condensation at equilibrium pressure and evaporation at equilibrium pressure leads to **disappearance of the hysteresis**.



Membrane production



Two step anodizing
in oxalic acid
($C_2H_2O_4$) at $0^\circ C$




Immersion in
 $27.2\text{ g } CuCl_2$
copper chloride
+ $0.2\text{ l } HCl(37\%)$
hydrochloric acid
+ $0.8\text{ l } H_2O$
water





Floating on
phosphoric acid
(H_3O_4P) till milky
aspects appear
plus 15 min




Alumina membranes - funnellization



Alumina membranes - funnellization





Alumina membranes - funnellization




Funnellization

Funnellization suspected due to different pore diameters on top and bottom side.




Alumina membranes - pore size distribution




Pore size distribution

SEM analysis shows pore size distribution on a given membrane.

Alumina membranes - corrugations




Alumina membranes - corrugations



Corrugations

The appearance of the hysteresis is assumed to be due to **intra pore corrugations**.



Alumina membrane defects

Isotherms are affected by

- Pore size distribution
- Funnellization
- Corrugations

Alumina membrane defects

Isotherms are affected by

- Pore size distribution
- Funnellization
- Corrugations


Problem

No simple ways to characterize these defects!


SEM images only give an impression of the surfaces of the membrane (factor between pore diameter and pore length is 1000!).

→ Need of **monodisperse membranes**

Experimental setup



Experimental setup



Volumetric and optical measurements

Volumetric and optical setups work independently.

Data evaluation

Inverse funnelling

Atomic layer deposition

SEM image analysis

um_Al₂6.tif.png